



Figure 1: Rudder Control System

Parts list

1. Master Cylinder Mounting Brackets - left side
 quantity needed: 2
 GlaStar part number: 602-01001-03
 GlaStar description: ANGLE, FRMD, 0.063 X 1 X 2-3/4 in

2. Master Cylinder Mounting Brackets - right side
 quantity needed: 2
 GlaStar part number: 602-01001-03
 GlaStar description: ANGLE, FRMD, 0.063 X 1 X 2-3/4 in

3. Rudder Pedal Brake Actuator Bracket - left side
 quantity needed: 1
 GlaStar part number: 601-01103-03

GlaStar description: ANGLE, FRMD, .050 X 8.75 X 3

4. Rudder Pedal Brake Actuator Bracket - right side

quantity needed: 1

GlaStar part number: 601-01103-03

GlaStar description: ANGLE, FRMD, .050 X 8.75 X 3

5. Rudder Pedal Pivot Bracket - left side

quantity needed: 1

GlaStar part number: 601-01102-03

GlaStar description: ANGLE, FRMD .050 X .75 X 1.55X

4. Rudder Pedal Pivot Bracket - right side

quantity needed: 1

GlaStar part number: 601-01102-03

GlaStar description: ANGLE, FRMD .050 X .75 X 1.55X